

Patching & Leveling Latex Additive

1 Product Name

Patching & Leveling Latex Additive

2 Manufacturer

Custom Building Products
 Technical Services
 10400 Pioneer Boulevard, Unit 3
 Santa Fe Springs, CA 90670
 Customer Support: 800-272-8786
 Technical Services: 800-282-8786
 Fax: 800- 200-7765
 Email: contactus@cbpmail.net
custombuildingproducts.com

3 Product Description

Increases adhesion and performance when skim coating or patching hard-to-bond surfaces. Use in place of water to increase the bond strength of appropriate CUSTOM patching compounds. When mixed with an appropriate CUSTOM patching compound, it forms an ultra, high-strength system over ceramic tile, stone, terrazzo, vinyl sheet goods, VCT or cutback adhesive residue.

Key Features

- Increases bond strength of patching and leveling compounds
- Improves adhesion over hard-to-bond surfaces
- Mix with Skim Coat & Patch for an ultra high-strength system

Uses

Use in place of water for increased bond strength.

Suitable Tile Types

- Ceramic tile, pavers, brick
- Stone, terrazzo
- Carpet
- Wood, parquet
- VCT
- Sheet vinyl flooring
- Laminated flooring

Suitable Substrates

- Concrete
- [WonderBoard® Lite](#) cement backerboards
- [RedGard® Waterproofing and Crack Prevention Membrane](#)
- Exterior Grade Plywood (interior applications)
- Ceramic tile, pavers, brick
- Stone
- Concrete terrazzo
- Sheet vinyl
- VCT
- Cutback adhesive (non-water soluble)

Packaging

1 Gallon (3.78 L) Bottles



4 Technical Data

Applicable Standards

American National Standards Institute (ANSI) ANSI A108.01 and A108.02 of the American National Standards for the Installation of Ceramic Tile ASTM International (ASTM)

- ASTM C109 Standard Test Method for Compressive Strength of Hydraulic Cement Mortars (Using 2-in. or (50-mm) Cube Specimens)
- ASTM C531 Standard Test Method for Linear Shrinkage
- ASTM C580 Standard Test method for Flexural Strength Resilient Floor Covering Institute (RFCI) Recommended Work Practices for Removal of Resilient Floor Coverings

Tile Council of North America (TCNA) TCNA Handbook for Ceramic Tile Installation, TCNA Method EJ171

Environmental Consideration

Custom® Building Products is committed to environmental responsibility in both products produced and in manufacturing practices. Use of this product may contribute to LEED® certification.

5 Instructions

General Surface Prep

USE CHEMICAL-RESISTANT GLOVES, such as nitrile, when handling product.



CUSTOM®

Patching & Leveling Latex Additive

Surfaces must be structurally sound, clean, dry and free from grease, oil, dirt, curing compounds, sealers, adhesives or any other contaminant that would prevent a good bond. Glossy or painted surfaces must be sanded, stripped and cleaned of waxes, dirt or any contaminants. Concrete must be cured 28 days and accept water penetration. Concrete must be free of efflorescence and not subject to hydrostatic pressure. Concrete slabs should have a broomed or brushed finish to enhance the bond. Plywood flooring including those under resilient flooring must be structurally sound and meet all ANSI and deflection requirements. For questions about proper subfloor installation, call Technical Services. Smooth concrete surfaces, existing glazed tile, terrazzo, or polished stone should be roughened or scarified. Sheet vinyl must be well-bonded and stripped of old finish. Roughen the surface by sanding or scarifying, rinse and allow to dry. Expansion joints should never be bridged with setting material. Do not sand flooring materials containing asbestos. Ambient temperature, surfaces and materials should be maintained at a temperature above 50° F (10° C) or below 100° F (38° C) for 72 hours.

Bonding to Concrete Surfaces

Concrete or plaster must be fully cured and must accept water penetration. Test by sprinkling water on various areas of the substrate. If water penetrates, then a good bond can be achieved; if water beads, surface contaminants are present, and loss of adhesion may occur. Contaminants should be mechanically removed before installation. Concrete must be free of efflorescence and not subject to hydrostatic pressure. Concrete slabs should have a broomed or brushed finish to enhance the bond. Smooth concrete slabs must be mechanically abraded to ensure a good bond.

Bonding to Lightweight Cement and Gypsum Surfaces

Lightweight or gypsum-based underlayments must first be treated with RedGard® Waterproofing and Crack Prevention Membrane and must obtain a minimum 2000 psi (13.8 MPa) compressive strength at the recommended cure time. The underlayment must be sufficiently dry and properly cured to the manufacturer's specifications for permanent, non-moisture permeable coverings. Surfaces to be tiled must be structurally sound and subject to deflection not to exceed the current ANSI Standards All lightweight concrete and gypsum-based underlayment surfaces to receive RedGard® must be primed with properly applied sealer or a primer coat of RedGard®, consisting of 1-part RedGard® diluted with 4-parts clean, cool water. Mix in a clean bucket at low speed to obtain a lump-free solution. The primer can be brushed, rolled or sprayed to achieve an even coat. Apply the primer coat to the floor at a rate of 300 ft/gallon (7.5 M/L). Drying time depends on site conditions, but is normally less than 1 hour. Extremely porous surfaces may require 2 coats. At this point, RedGard® can be applied to the primed lightweight or gypsum-based surface. Refer to the individual product data sheet or packaging directions for application instructions. Expansion joints must be installed in accordance with local building codes and ANSI/TCNA guidelines. Refer to TCNA EJ171.

Bonding to Plywood Surfaces

Plywood floors, including those under resilient flooring, must be structurally sound and must meet all ANSI A108.01 Part 3.4 requirements. See TCNA F150. For questions about proper subfloor installation, call Custom® Building Products.

Bonding to Backerboards

As an alternative to an additional layer of plywood, WonderBoard® Lite Backerboard may be installed over plywood subfloors.

Bonding to Cutback Adhesive

Adhesive layers must be removed, as they reduce mortar bond strength to cement surfaces. Use extreme caution; adhesives may contain asbestos fibers. Do not sand or grind adhesive residue, as harmful dust may result. Never use adhesive removers or solvents, as they soften the adhesive and may cause it to penetrate into the concrete. Adhesive residue must be wet-scraped to the finished surface of the concrete, leaving only the transparent staining from the glue. To determine desirable results, do a test bond area before starting. Refer to the RFCI Pamphlet, "Recommended Work Practices for Removal of Resilient Floor Coverings", for further information.

Mixing Ratios

Use in place of water following the directions on the patching compound packages.

Application of Product

Follow application instructions on the patching compound packages.

Cleaning of equipment

Clean with water before material dries.

Storage

Protect from freezing. Store in a cool, dry area.

Health Precautions

Contains latex emulsion. Wear rubber gloves and eye protection. Avoid eye contact or prolonged contact with skin. Wash thoroughly after handling. If eye contact occurs, flush with water for 15 minutes and consult a physician. If skin contact occurs, wash immediately with soap and water. Dried material is extremely difficult to remove. KEEP OUT OF REACH OF CHILDREN. DO NOT TAKE INTERNALLY.

Conformance to Building Codes

Installation must comply with the requirements of all applicable local, state and federal code jurisdictions.

6 Availability & Cost

Item Code	Size	Package
LQLA1	1 gallon (3.78 L)	Bottle
CLQLA1 (Canada)	1 gallon (3.78 L)	Bottle

7 Product Warranty

Obtain the applicable **LIMITED PRODUCT WARRANTY** at www.custombuildingproducts.com/product-warranty or send a written request to Custom Building Products, Inc., Five Concourse Parkway, Atlanta, GA 30328, USA. Manufactured under the authority of Custom Building Products, Inc. © 2017 Quikrete International, Inc.

8 Product Maintenance

Properly installed product requires no special maintenance.



CUSTOM®

Patching & Leveling Latex Additive

9 Technical Services Information

For technical assistance, contact Custom technical services at 800-282-8786 or visit custombuildingproducts.com.

10 Filing System

Additional product information is available from the manufacturer upon request.

Related Products

SpeedFinish™ Patching & Finishing Compound

Skim Coat & Patch Cement Underlayment