



Save days, not hours, on a shower installation.

RAPID CURING **REDGARD[®]**
SPEEDCOAT[™]
Rapid Curing Waterproofing Membrane

SAME COVERAGE
AS TRADITIONAL
3.5 GALLON
WATERPROOFER*



- Exceptionally fast cure time — one coat cures in as little as one hour
- Revolutionary cross-linking, moisture-cure technology — ideal from hot/humid to cold/damp conditions
- One gallon waterproofs a standard-size shower
- Excels on freshly installed mortar beds



RedGuard® SpeedCoat™ is a revolutionary new formula. Its cross-linking, moisture-cure technology allows for fast cure times even in cold and damp conditions. Suited for both commercial and residential shower installations, RedGuard SpeedCoat creates a continuous waterproofing barrier with outstanding adhesion in tile and stone floors. It bonds directly to clean metal, PVC, stainless steel and ABS drain assemblies.

It meets uniform plumbing code specifications for use as a shower pan liner; listed with IAPMO R&T, file 4244 UPC®, ICC-ES ESR1413

Key Features

- Ready to use liquid-applied waterproofing membrane
- Listed with IAPMO for use as a shower pan liner

Product Benefits

- Reduces curing time with exceptionally quick-dry formula
- As little as one hour cure after final coat before flood test or tile installation
- Works effectively in “challenging conditions” of high moisture and either cold or hot temperature
- Easy to use and is applied by roller or trowel
- Rated for extra heavy duty service
- Meets Uniform Plumbing Code specifications for use as a shower pan liner
- Can be applied to young concrete

Suitable Substrates

- Concrete, cement mortar, masonry
- Cement Backerboard Units (CBU)

Available Sizes

	Item Code	Size
USA	RGSC1-2	1 gallon (3.78 L) Pail
Canada	CRGSC1-2	1 gallon (3.78 L) Pail

*Average Coverage

	IAPMO Shower Pan		General Waterproofing	
	Coats	Coverage	Coats	Coverage
Over CUSTOM SpeedSlope® Rapid Setting Sloping Mortar; or WonderBoard® Lite Backerboard and other smooth concrete	2	110 ft² (10.2 m²)	1	220 ft² (20.4 m²)
Over Portland Cement Mortar Beds	2	65 ft² (6 m²)	1	130 ft² (12 m²)

Chart for estimating purposes. Coverage may vary based on installation practices and jobsite conditions. Use the material calculator at CustomBuildingProducts.com or contact CUSTOM Technical Services at 800-282-8786.

Average Curing Time Required For Full Waterproofing And Flood Testing (2 Coats Used For All Conditions)**

	RedGuard® SpeedCoat™	Traditional Liquid Membrane
Cold/wet	4 hours	4 days
Cold/dry	8 hours	>1 day
Hot/wet	2 hours	>1 day
Hot/dry	2 hours	24 hours

** Times are approximate and can vary based on installation practices and jobsite conditions.



SpeedSlope™

Combine RedGuard® SpeedCoat™ with SpeedSlope™ Rapid Setting Sloping Mortar for the ultimate fast-curing shower prep system.



Select a qualifying system of Prep, Set and Grout products and CUSTOM will warranty the tile installation for life, including tile, materials and labor. See website for complete details.

©2016 Custom Building Products. All rights reserved. The CUSTOM® logo and select product logos are registered trademarks of Custom Building Products, Inc. CUSTOM may make product modifications at any time without notice. Visit custombuildingproducts.com for updated technical data sheets and SDS information.

Custom Building Products
800-272-8786
custombuildingproducts.com

SS165 8/16R

