

RECOMMENDED MORTARS FOR THE INSTALLATION OF STONE OR CERAMIC TILE WITH ECORE QTSCU

Custom Building Products recommends the use of FlexBond®, MegaFlex® or MegaLite® Crack Prevention Mortar for the installation of stone or ceramic tile to the proper installation of ECORE QTscu per manufactures instructions and industry standards.

For specific assemblies, please refer to manufacturer's recommendations as set forth by ECORE QTscu installation instructions.

The performance responsibilities of Custom Building Products thin-set mortar to the surface area of ECORE QTscu are deferred to the warranties of ECORE. Any claims should be referred to ECORE.

WARRANTY

Custom Building Products warranties do not cover the installation or performance of ECORE QTscu. Custom Building Products' 1-Year Limited Product Warranty does cover the performance of our thin-set mortar's contact with the back side of the tile and the substrate according to industry standards. Any performance claims should be referred to Custom Building Products. Information concerning the installation of tile with Custom Building Products FlexBond, MegaFlex or MegaLite Crack Prevention Mortar, can be obtained at custombuildingproducts.com.

RELATED PRODUCTS

MegaLite® Crack Prevention Mortar

MegaFlex® Crack Prevention Mortar

FlexBond® Crack Prevention Mortar

The information in this bulletin is presented in good faith, but no warranty, express or implied, is given nor is freedom from any patent in as much as any assistance furnished by Custom with reference to the safe use and disposal of its products provided without charge. Custom Building Products assumes no obligation or liability therefore, except to the extent that any such assistance shall be given in good faith.

Technical Bulletin

Technical Services 800-282-8786
custombuildingproducts.com

