#### 1 Product Name

Wood UR4 Ultimate Adhesive

### 2 Manufacturer

Custom Building Products 7711 Center Avenue Suite 500 Huntington Beach, CA 92647

Customer Support: 800-272-8786 Technical Services: 800-282-8786

Fax: 800- 200-7765
Email: contactus@cbpmail.net custombuildingproducts.com

## 3 Product Description

Wood UR4 is a supreme handling urethane adhesive that does the job of four products, all in one application. Ideal for the most critical jobs, this 4-in-1 product works as an adhesive, concrete moisture control, sound reducer and crack isolation membrane. Additionally, WOOD UR4 is one of the most elastic urethanes on the market, allowing for naturally occurring expansion and contraction of wood.

Suitable as an adhesive

- Solid Wood Plank
- · Engineered Wood Plank
- Bamboo (not strand woven)
- Ceramic Tile
- · Natural Stone Inlays
- Plywood Panels [for nail down/double bond installations]
- Underlayments [Recycled rubber/cork]

### **Key Features**

### Features/Benefits of Product in the Installation

- 4-in-1 technology reduces install time and eliminates need for multiple products
- Single application moisture barrier and adhesive reduces material and labor costs.
- Sound reduction and crack bridging capabilities for the most challenging applications
- Highly elastic formula allows for expansion and contraction without damaging adhesive

# **Suitable Substrates**

- Cement-based self-leveling underlayment and patching compounds
- Cement/epoxy terrazzo
- Concrete (industry approved) at least 14 days old with an appropriate moisture vapor barrier properly installed under slab
- Epoxy Coatings
- Existing well bonded floor coverings
- Plywood and other approved wood substrates
- Properly prepared primed/sealed gypsum underlayment per ASTM F2419
- Radiant heated floors (temperature should not exceed 85° F)
- \* All surfaces / substrates above require proper surface preparation

## **Acceptable Substrate Conditions**

Published Date: 12/7/2020



- RH ≤90 % / ASTM F2170 Relative Humidity in Concrete Floor Slabs
   situ Probes Vapor Emission Rate See wood flooring manufacture for product limitations and requirements
- MVER ≤15 lbs / ASTM F1869 Measuring Moisture Vapor Emission Rate of Concrete Subfloor Using
- pH [Substrate] up to 12

#### Limitations to the Product

IMPORTANT NOTE: Install flooring in areas suitable per wood flooring manufactures written instructions.

- · For interior use only
- Do not use when ambient and/or substrate temperature is below 50° F (10° C) or above 95° F (35° C) or when condensation exists
- · Do Not install over surfaces with condensation or standing water
- Not for use in areas subject to hydrostatic moisture conditions
- Concrete substrate temperatures must be above dew point/condensation
- Not for use as a moisture mitigation system under any other flooring types [see CustomTECH™ MVC]
- · Not for use with solid vinyl, vinyl backed carpet flooring
- Existing adhesive must be removed to an embedded residue with no surface trowel ridges
- Do not install over treated plywood
- · Do not dilute with water, solvents or any chemicals



### 4 Technical Data

### **Applicable Standards**

- NWFA / National Wood Flooring Association Wood Flooring Installation Guidelines
- ASTM F710 Standard Practice for Preparing Concrete Floors to Receive Resilient Flooring
- ASTM E96 Standard Test Methods for Water Vapor Transmission of Materials
- ASTM E492 Standard Test Method for Laboratory Measurement of Impact Sound Transmission
- ASTM E90 Standard Test Method for Laboratory Measurement of Airborne Sound Transmission Loss of Building Partitions and Elements
- ASTM E2179 Standard Test Method for Laboratory Measurement of the Effectiveness of Floor Coverings in Reducing Impact Sound Transmission Through Concrete Floors
- ICRI / International Concrete Institute
- ASTM F2170 Relative Humidity in Concrete Floor Slabs using in situ Probes
- ASTM F1869 Measuring Moisture Vapor Emission Rate of Concrete Subfloor Using Anhydrous Calcium Chloride
- ASTM F2419 Standard Practice of Thick Poured Gypsum Concrete Underlayments and Preparation of the Surface

### **Technical Chart**

Product Data	Composition	100% Moisture Curing Polyurethane
	Appearance	Thick Creamy Paste
	Base color	Tan Brown
Product Timing	Open/Working time	60-90 minutes
Service	Installation - Light Traffic	4 hours
Timing	Installation - Moderate/Heavy	24 hours
	Installation - Full Service / Heavy Rolling	48 hours
Moisture	RH / Relative Humidity	up to 90%
Data	MVER/Moisture Vapor Emission Rate	up to 20 lbs.

Storage	Shelf life	1 year — stored in original unopened packaging at 73° F (23° C)
	Storage Conditions required	50° F to 100° F (4° C to 38° C)

Environmental	Solvents	Minimal
and Sustainability	VOCs (Rule #1168 of California's SCAQMD)	<30 g/L
	*LEED Credits / MR5 and IEQ 4.1	Regional and low emitting materials

Published Date: 12/7/2020

Health and	CAUTION WARNING	Irritant, Sensitizer
Safety	Contains	MDI isocyanate May cause skin and respiratory sensitization.
	Before using product read Safety Data Sheet (SDS).	Intentional misuse by deliberate concentration and inhalation of vapors may be harmful or fatal.

Sound Reduction Ratings - 3/4" Thick Uncoated Pine Wood Flooring Over 6" concrete slab			
Specification	No Suspended Ceiling	Suspended Gypsum Ceiling	
ASTM E 492-09 (2016) e1 / E989-18	47 (NGC 7020167)	68 (NGC 7020169)	
ASTM E 2179-03 (2016)	19 (NGC 7020168)	N/A	

### ASTM E 2179-03 (2016)

### **Environmental Consideration**

Custom® Building Products is committed to environmental responsibility in both products produced and in manufacturing practices. Use of this product may contribute to LEED® certification.

# 5 Instructions

# Installation

- Use Proper PPE/Personal Protective Equipment when handling product
- 2. Install per wood flooring manufactures instructions.
- 3. Remove all surface water before installation.
- Allow for normal wood expansion at wall perimeter and all restraining abutments, see wood manufactures instructions and requirements.
- 5. Using the appropriate trowel to apply adhesive that can be covered within 60 minutes. Do not allow adhesive to dry before installation of wood or floor covering.
- 6. For moisture barrier performance use the required trowel size referenced in Install/Coverage chart below. NOTE: To maintain the product warranty is critical to achieve 100% coverage.
- 7. Press firmly into the wet adhesive bed to compress all ridges and maintain a continuous film defined by trowel notches.
- 8. Occasionally lift up a board and check the subfloor for 100% coverage which is critical for moisture control. If proper transfer is not achieved, reapply using the recommended trowel.



- 9. Use of adhesive for ceramic tile and stone installations should be limited to insets and complimentary designs to wood installation. For larger areas, it is recommended to use a suitable Custom Building Products tile/stone adhesive.
- 10. Evaluate suitability with tile and natural stone. In specific, the potential for staining of natural stone or absorptive tiles.
- 11. Working and drying time of the adhesive is influenced by temperature, humidity of the room, air-flow and substrate temperatures/porosity. Roll flooring's width and length with manufacture's recommended weight roller.
- 12. PROTECTION General Contractor, Flooring Contractor and Building owner must provide proper climate controls per flooring manufacturers requirements before, during and after flooring installation.

### **General Surface Prep**

All surfaces must be structurally sound, without excessive deflection, clean, dry and free from contaminants that would prevent or inhibit adhesion bonding. Concrete and cement-based underlayment/patching compounds used to repair flatness deviations must be fully cured and not exhibit signs of moisture or hydrostatic conditions/issues.

Concrete substrates must have porosity/absorption as outlined by ASTM F3191 Field Determination of Substrate Water Absorption, a droplet of water must absorb into concrete within 1 minute. Concrete surfaces must meet a #1-3 CSP/Concrete Surface Profile (not polished/reflective) as defined by ICRI/International Concrete Repair Institute's Guideline No. 03732. Substrates should be free of laitance, contaminants, surface/dissipating curing compounds. To remove curing compounds, construction debris, open up non absorptive concrete substrates, shot-blasting and/or diamond grinding methods are best methods to prepare and clean when and where necessary.

All surfaces must be flat, sound and stable. Floor Flatness requirements of 3/16" allowable variation in 10 ft. apply and/or per wood manufacture and NWFA Installation Guidelines.

Any sources of moisture are to be limited to initial concrete placement and not from sources such as water intrusion or from a lack of an effective vapor retarder/barrier under concrete slab. Substrate must be prepared per ASTM F710 standards.

It is the responsibility of the installer to determine the suitability of the substrate and any required preparation work necessary to ensure a successful installation.

Assembly mockups will determine suitability for these conditions on specific projects. Contact CUSTOM Technical Services for product information (800) 282-8786.

Fill all surface cracks, grooves, depressions, control joints and nonmoving joints According to ASTM F710. Contaminants or curing compounds should be mechanically removed before installation.

Concrete must be free of efflorescence and hydrostatic pressure conditions. All concrete surfaces must have a minimum tensile strength in excess of 200 psi (1.4 n/mm²). HVAC must be operational between 60-95°F/30-65% relative humidity for ambient conditions a minimum of 72 hours prior to installation enabling the substrate and adhesive to be properly acclimated. Consult the flooring manufacture for site conditioning requirements and acclimation requirements of their materials. Large temperature and relative humidity discrepancy will affect the working time of the adhesive. Disable radiant system 24 hours prior, during and after installation – Follow radiant system manufacture's instruction for start-up procedures.

Published Date: 12/7/2020

### Cleaning of equipment

Consult the wood manufacture for cleaning wood finish surface instructions. To remove cured adhesive from prefinished flooring, use a citrus cleaner or mineral spirits. Apply the adhesive remover to the affected area with a non-abrasive towel and allow to sit for 5-10 minutes to soften the adhesive. Then buff the adhesive off with the non-abrasive towel. Use personal protective equipment (chemical resistant gloves/ goggles/clothing). Without direct contact, remove spilled or excess product and placed in suitable sealed container. Dispose of excess product and container in accordance with applicable environmental regulations.

### **Conformance to Building Codes**

Installation must comply with the requirements of all applicable local, state and federal code jurisdictions.

### 6 Availability & Cost

Contact the manufacturer or visit custombuildingproducts.com for information about product cost and availability.

ITEM CODE	SIZE	PACKAGE
UAWAT5	5 gal (18.9 L)	Pail

## 7 Product Warranty

- 2 Years Product only, unopened and properly stored.
- 15 Year System CUSTOM Adhesive and CustomTECH Floor Preparation Systems.
- FLOOR-MATCH Warranty CUSTOM Adhesives & CustomTECH Floor Preparation Products/Systems are warranted equal to the Flooring manufacturer's warranty term up to LIFETIME. \*See CUSTOM FLOOR-MATCH Warranty, separate document.

## 8 Product Maintenance

Follow wood flooring manufacturers written instructions for proper maintenance, chemicals and techniques.

Properly installed product requires no special maintenance, see flooring manufacture for service and maintenance requirements.

### 9 Technical Services Information

For technical assistance, contact Custom Technical Services at (800) 282-8786 or contact us online at custombuildingproducts.com.

### 10 Filing System

Additional product information is available from the manufacturer upon request.



### Coverage

CHART BELOW IS FOR INSTALLATIONS THAT ARE FOR ADHESIVE ONLY

SQUARE FOOT COVERAGE PER GALLON (SQUARE METER PER 3.8 L)		
Wood Flooring > 5/8" (16 mm) thick	30 - 35 sq. ft. (2.79 - 3.25 M²)	1/4" x 1/4" x 1/4" (6.4 x 6.4 x 6.4 mm) SQ
Solid or Engineered Wood from 1/2" to 5/8" (12.7-16 mm) thick	40 - 50 sq. ft. (3.72 - 4.65 M²)	1/4" x 1/8" x 1/4" (6.4 x 3.2 x 6.4 mm) SQ
Engineered Wood up to 1/2" (12.7 mm) thick	45 - 55 sq. ft. (4.18 - 5.11 M²)	3/16" x 5/32" (4.8 x 4.0 mm) V

# CHART BELOW IS FOR INSTALLATIONS THAT REQUIRE SUBFLOOR MOISTURE PROTECTION

SQUARE FOOT COVERAGE PER GALLON (SQUARE METER PER 3.8 L)		
Wood Flooring > 5/8" thick	30 - 35 sq. ft. (2.79 - 3.25 M²)	1/4" x 1/4" x 1/4" (6.4 x 6.4 x 6.4 mm) SQ
Wood Flooring 1/2" to 5/8" (12.7- 16 mm) thick	40 - 50 sq. ft. (3.72 - 4.65 M²)	1/4" x 1/8" x 1/4" (6.4 x 3.2 x 6.4 mm) SQ
Wood Flooring up to 1/2" (12.7 mm) thick	45 - 55 sq. ft. (4.18 - 5.11 M²)	3/16" x 5/32" (4.8 x 4.0 mm) V

Chart for estimating purposes. Coverage may vary based on installation practices and jobsite conditions. For more sizes, use the material calculator at CustomBuildingProducts.com or contact CUSTOM Technical Services at 800-282-8786.



Published Date: 12/7/2020