

Aqua Mix Technical Bulletin #7:

REMOVAL OF SOAP SCUM, HARD WATER DEPOSITS AND MILDEW STAINS

Purpose: To remove water deposits, mildew and soap scum on tile and acid-resistant stone surfaces

Product Recommendation: Phosphoric Acid Substitute (Note A)

Equipment: White nylon scrub brush or scrub pad

Coverage: Varies depending on use and amount of buildup

Procedure:

1. Always test a small area first to ensure satisfactory results.
2. Apply pre-diluted solution to surface.
3. Agitate with a white nylon scrub brush or scrub pad.
4. For stubborn areas, allow to dwell 5 to 10 minutes before agitating.
5. Rinse thoroughly with clean water.

Note A: Do not use on polished marble, limestone or on other acid-sensitive tile or stone. For acid-sensitive surfaces, Aqua Mix NanoScrub® is recommended per product directions.

These recommendations are intended as general guidelines for the removal of soap scum/mildew stains/hard water deposits. The actual removal requirements may vary depending on the use and amount of mildew and/or soap scum to be removed. READ PRODUCT DIRECTIONS THOROUGHLY PRIOR TO USE. ALWAYS TEST FIRST. KEEP SURFACE CLEAN AND DRY TO REDUCE POSSIBILITY OF SLIP-FALL ACCIDENTS.