


LevelQuik Advance



1. Product Name

LevelQuik Advance

2. Product Description

LevelQuik® Advance is a high-flow, fiber-reinforced self-leveling underlayment that offers the unique advantage of being a versatile solution perfect for all construction and renovation projects. Its compatibility with various substrates, including wood subfloors without the need for lath, concrete, ceramic tile, and existing flooring, makes it an excellent choice for diverse applications. This innovative product eliminates the necessity for additional materials like cement backerboard, simplifying the installation process while ensuring a seamless, flat surface.

Key Features

- Advanced formula for all substrates
- No lath required for plywood and OSB subfloors.
- Cures fast and develops high early strength for quick installation.
- Can be applied from 1/4" to 1.5" (3.8 cm) thick in a single pour.
- Low Prep Formula; Just Sweep, Prime & Pour- no sand blasting required on acceptable surfaces.
- Compatible with most radiant heating systems Replaces the need for cement backerboard.
- Exceeds TCNA and ASTM requirements for ceramic tile and resilient floor covering installations.
- Superior Crack Resistance - Formula reduces shrinkage & minimizes cracks.
- Zero flame spread per ASTM E84 Standard Test Method for Surface Burning Characteristics of Building Materials

Uses

Suitable as an Underlayment for:

- Carpet
- Wood and parquet flooring
- Luxury Vinyl Tile/Planks (LVT/LVP) Vinyl composition flooring (VCT)
- Sheet vinyl and rubber flooring Laminated flooring
- Ceramic, mosaic, quarry or cement body tile
- Impervious porcelain and glass tile
- Cement-based precast terrazzo
- Natural stone tile
- Terrazzo

Suitable Substrates

- APA rated 3/4" (18mm) T&G Type 1 exterior exposure plywood or OSB equivalent over 16" joists for most finishes

(An additional plywood layer and/or floor support may be required for dimensionally weaker finishes such as natural stone, Saltillo, cement and glass tiles.)

- Concrete
- Gypsum-based underlayment Existing ceramic tile
- Cement terrazzo or epoxy terrazzo
- Cutback adhesive residue resilient flooring

Composition of Product

LevelQuik® Advance is a dry, proprietary blend of copolymers, Portland cement, post industrial and consumer recycled aggregate and inorganic chemicals

Benefits of Product in the Installation

- No lath required for wood frame and OSB subfloors
- No shot blasting required on acceptable surfaces Can be applied from 1/4" to 1.5" thick in a single pour
- Reduces bond failure and crumbling of resilient flooring
- Cures fast and develops high early-strength for quick installation
- Rated for extra heavy use on concrete per ASTM C627

Limitations to the Product

- For use in interior dry areas. Ambient, substrate and product temperature is to be between 50° F (10° C) 90° F (32° C).
- Chill or warm water when needed to make mixture fall between these temperatures.
- Assure that substrates are not wet from condensation in ambient conditions of high humidity. High humidity conditions may affect surface drying and subsequently final results.
- Do not bond directly to hardwood, Luan plywood, particle board, parquet, cushion or sponge-back vinyl flooring, metal, fiberglass or plastic. Contact technical services for recommendations.
- Do not use as a permanent wear surface.
- Do not use on sloped surfaces that require drainage.
- Precautions for finished flooring deflection and movement joint requirements should be considered when applying over post-tensioned concrete, pre-stressed concrete or prefabricated concrete planks. Contact technical services for further details.

Packaging

50 lb (22.68 kg) bags

3. Technical Data

Applicable Standards

ASTM International (ASTM)

- ASTM C1708 Standard Test Methods for Self-leveling Mortars Containing Hydraulic Cements
- ASTM F2873 Standard Practice for the Installation of Self-Leveling Underlayment and the Preparation of Surface to Receive Resilient Flooring
- ASTM C627 Standard Test Method for Evaluating Ceramic Floor Tile Installation Systems Using the Robinson-Type Floor Tester
- ASTM F2170 Standard Test Method for Determining Relative Humidity in Concrete Floor Slabs Using in situ Probes
- ASTM F1869 Standard Test Method for Measuring Moisture Vapor

LevelQuik Advance

- o ASTM F710 Standard Practice for Preparing Concrete Floors to Receive Resilient Flooring

Resilient Floor Covering Institute (RFCI) Recommended Work Practices for Removal of Resilient Floor Coverings

Tile Council of North America (TCNA) TCNA Handbook for Ceramic Tile Installation, TCNA Method EJ171

American National Standards Institute (ANSI) ANSI A108.01 and A108.02 of the American National Standards for the Installation of Ceramic Tile

Technical Chart

Technical Chart

Property	Test Method	Typical Results @70°F (21°C) and 50%RH
Pot Life (in bucket)		>15 minutes
Healing Time (Re-heal)	ASTM C-1708	>10 minutes
Compressive Strength at 28 days	ASTM C-1708	3,500 – 4,000 psi
Flexural Strength at 28 days	ASTM C-348	>1350 psi (9.3MPa)
Walkable Hardness		2-4 Hours
Robinson Test	ASTM C-627	Extra Heavy
Time Before Installing Flooring		
Ceramic tile/Non-moisture sensitive floor covering		>4 Hours
Moisture-sensitive floor coverings		>16 Hours

Environmental Consideration

Custom® Building Products is committed to environmental responsibility in both products produced and in manufacturing practices.

Use of this product may contribute to LEED® certification.

Complies with CA Section 01350 and CDPH V1.2-2017.



4. Instructions

General Surface Prep

Always wear proper protective equipment when handling the product, including IMPERVIOUS GLOVES, such as nitrile, safety glasses, and a NIOSH N95 respirator (mask).

All surfaces must be structurally sound, clean, dry and free from contaminants such as grease, oil, dirt, dust, curing compounds, waxes, sealers, efflorescence, or any other foreign matter. Concrete must be fully cured and absorb water. Smooth concrete surfaces, existing glazed tile, terrazzo, or polished stone may need to be roughened or scarified. Refer to MBP Multi

Surface Bonding Primer technical datasheet for use in lieu of mechanical preparation or when applying over nonporous substrate and CustomTech MVC Moisture Vapor and Alkalinity Barrier. For

increased performance in demanding applications, concrete surfaces can be mechanically profiled and prepared by shotblasting, sandblasting, scarifying, diamond-grinding or other engineered approved methods (reference ICRI CSP 3 standards for ideal profile height). Any existing flooring must be well bonded and stripped of old finish.

CUSTOM® products may be used in assemblies over concrete with high moisture vapor emission levels provided that other materials such as finish flooring, adhesives or membranes are approved in these conditions. Consult the manufacturers for their limitations and requirements. Additionally, any sources of moisture are to be limited to initial concrete placement and not from sources such as water intrusion or from a lack of an effective vapor retarder/barrier.

Assembly mockups will determine suitability for these conditions on specific projects. Contact CUSTOM Technical Services for product information (800) 282-8786

Bonding To Concrete Surfaces

In addition to general surface preparation requirements listed above, concrete must be free of efflorescence and hydrostatic pressure. Concrete surfaces must have a tensile strength in excess of 200 psi (1.4 n/mm²). Concrete that was treated with curing compounds must be evaluated for suitability or mechanically removed.

Bonding to Plywood and OSB Surfaces

Bonding to Plywood and OSB Surfaces Plywood shall be a minimum ¾" (19 mm) tongue & groove, APA rated Type 1 exterior exposure plywood. Subfloors shall be structurally compliant to building codes and area usage including joist blocking or bracing, be sound, clean, dry, and free from contaminants that would prevent adhesion. Any loose or deflecting areas must be addressed prior to leveler installation. Floors may be prepared by sanding. Do not use sweeping compounds, or chemicals or solvents to clean the floor. It is generally accepted that wood-framed substrate deflection for Porcelain tiles is limited to <L/360; natural stone <L/720. Dimensionally weaker finishes such as natural stone, Saitillo, cement, glass tile and resilient flooring installations may require additional plywood layers based on area size/span; deflection; leveler thickness and project usage, live and dead loads. Leveler may require 1/2" thickness to replace cement backerboard use under tile. To help prevent failures from substrate creep (sagging), install heavy dead loads such as stone countertops prior to leveler and tile or flooring installation. Refer to ANSI A108 AN2 General Requirements for Subsurfaces and TCNA details for further information for tile installations or contact CUSTOM Technical Services. Block any open spaces to prevent leveler spilling to adjoining areas. Fill joints with a CUSTOM patching compound such as CUSTOM [SpeedFinish™ Patching & Finishing Compound](#) or prefill with LevelQuik Advance mixed at the minimum water level. All wood subfloors require a primer application of undiluted LevelQuik Advance.

Bonding to Cutback Adhesive

Adhesive layers must be removed. Use extreme caution; adhesives may contain asbestos fibers. Do not sand or grind adhesive residue, as harmful dust may result. Never use adhesive removers or solvents, as they soften the adhesive and may cause it to penetrate into the concrete. Adhesive residue must be wet-scraped to the finished surface of the concrete, leaving only the transparent staining from the glue. To determine desirable results, do a test bond area before starting. Refer to the RFCI Pamphlet "Recommended Work Practices for Removal of Resilient Floor Coverings" for further information.

Priming

Prime all surfaces with an appropriate Custom® primer before application of LevelQuik Advance. Refer to LevelQuik Advance datasheet.

LevelQuik Advance

Movement Joint Placement Joints or Cracks in Substrate

Expansion joints and cold joints, as described in ANSI A108.01, should be carried from the substrate up through the tile or flooring surface and filled with an appropriate elastomeric sealant, such as Custom's® [Commercial 100% Silicone Sealant](#). For the proper treatment of control or saw cut joints and cracks for flooring, refer to ASTM F710. For tile installations, refer to TCNA Details EJ171, F125 & F125A. Contact Custom Technical Services for additional information.

Mixing Ratios

Mix the entire 50 lb. (22.68 kg) bag of powder with 4.25 - 4.5 quarts (4-4.25 L) of clean, cool water.

Mixing Procedures Barrel:

Mix 50 lb. (22.68 kg) bag of powder with the appropriate amount of clean, cool water. Slowly add powder to water while mixing with a heavy-duty 1/2" (13 mm) electric drill and an eggbeater mixing paddle at minimum 650 RPM. Thoroughly mix for 2 minutes to a lump-free consistency. Do not overmix. Overmixing or moving the mixer up and down during the mixing process could trap air, which could shorten the pot life or cause pin holing during application and curing.

Pumping:

LevelQuik Advance can be pumped with a mixing pump. Adjust the water setting to obtain the optimum workability. Do NOT overwater. Pump the mix and use spreader to evenly distribute the materials to desired thickness.

Application of Product

Pour the mixed product and spread with a long-handled gauge rake to the desired thickness. Directly after the topping has been dispersed, use a smoothing blade to break the material's surface rheology and blend any inconsistencies to create a more uniform or homogeneous appearance. Keep a wet edge when pouring multiple mixes in the same area.

If a second layer is required, install immediately after the first layer has set to a walkable hardness. If the first layer has dried over 12 hours, re-prime before second application.

*** Always install a test area to confirm proper bonding as well as a desired appearance.

IMPORTANT NOTES: Self leveling cement based products may exhibit slight cracking due to structure and substrate moment; shrinkage; and creep. Sharp or reentrant wall corners can contribute to crack formation. These cracks are considered normal. Other causes of cracking are due to high ambient or substrate temperatures; wind or air flow; water ratios and mixing technique. When surface is sealed with clear or semi-transparent coatings, these cracks may become more visible.

Curing of Product


Install non-moisture-sensitive ceramic tile or stone in 4 hours; most floor coverings can be installed after 16 hours. Drying time can vary with temperature and humidity. Confirm moisture limitations of flooring and adhesives before installing over leveler.

Cleaning of Equipment

Clean with water before the material dries.

Health Precautions

DANGER: CAUSES SEVERE SKIN BURNS AND SERIOUS EYE DAMAGE. PROLONGED OR REPEATED INHALATION OF DUST MAY CAUSE LUNG DAMAGE OR CANCER. DO NOT BREATHE DUST OR SWALLOW. You cannot rely on pain to alert you to cement burns. Portland cement can cause dermatitis or sensitization. A NIOSH N95 respirator (mask) is recommended, especially in poorly ventilated areas, when use is frequent, or when permissible exposure limits may be exceeded. Immediately wash contaminated body and clothing thoroughly. If in eyes: rinse cautiously with water for several minutes; remove contact lenses if easy to do; continue rinsing. If inhaled: remove person to fresh air and keep comfortable for breathing. If swallowed: rinse mouth; do NOT induce vomiting. If you experience a burn, rash or skin irritation: immediately see a doctor. Immediately seek medical attention if any symptoms are significant or persist. In Emergency: 1-800-535-5053. **Contains portland cement and crystalline silica.** Before handling read Safety Data Sheet at www.custombuildingproducts.com. **KEEP OUT OF REACH OF**

CHILDREN.  **WARNING:** This product can expose you to chemicals including crystalline silica, which is known to the State of California to cause cancer, and hexavalent chromium compounds, which are known to the State of California to cause birth defects or other reproductive harm. For more information go to www.P65Warnings.ca.gov.

Conformance to Building Codes

Installation must comply with the requirements of all applicable local, state and federal code jurisdictions.

5. Size & Availability

Location	Item Code	Size	Package
USA	LQA50	50 lb (22.68 kg)	Bag
Canada	CLQA50	50 lb (22.68 kg)	Bag

Contact the manufacturer or visit custombuildingproducts.com for more information about product cost and availability.

6. Product Warranty

NOTICE: Obtain the applicable **LIMITED WARRANTY** at www.custombuildingproducts.com/product-warranty or send a written request to Custom Building Products, Inc., Five Concourse Parkway, Atlanta, GA 30328, USA. Manufactured by or under the authority of Custom Building Products, Inc. © 2024 Quikrete International, Inc.

7. Product Maintenance

Properly installed product requires no special maintenance. LevelQuik® RS is not recommended as a finish or wear surface.

8. Technical Services Information

For technical assistance, contact Custom® Building Products.

9. Filing System

Additional product information is available from the manufacturer

LevelQuik Advance

upon request.

Coverage Chart

TYPICAL SQUARE FOOT COVERAGE PER 50 LB BAG (SQUARE METER PER 22.68 KG)

THICKNESS	COVERAGE
1/4" (6.35 mm)	22 - 22.7 ft ² (2 - 2.1 M ²)
1/2" (12.7 mm)	11 - 11.4 ft ² (1 - 1.1 M ²)
1" (25.4 mm)	5.5 - 5.7 ft ² (0.51 - 0.53 M ²)
1.5" (38.1 mm)	3.6 - 3.7 ft ² (0.33 - 0.34 M ²)

Chart for estimating purposes. Coverage may vary based on installation practices and jobsite conditions. For more sizes, use the material calculator at CustomBuildingProducts.com or contact CUSTOM Technical Services at 800-282-8786.